

# **Assignment 1**

DATA MINING

CSE 572: Spring 2020

**Submitted by**

**Akshay Kumar([akuma216@asu.edu](mailto:akuma216@asu.edu))**

## **1. Assignment Phase 1: Feature Extraction**

As a part of assignment 1 we are given CGMData and CGMTime file to extract 4 features that are useful for the prediction process. I have started by looking into 5 different types of feature extraction techniques that can be useful for this time series data.

1. Fast Fourier Transform
2. Discrete Wavelet Transform
3. Velocity
4. Moving Average
5. Expanding Window





### **Question 1 and 2**

#### **1.FAST FOURIER TRANSFORM**

Fast Fourier Transform is used to extract frequency-based information from the time series data. We only select those frequency components which show high variance and keep it as a good feature among the whole array. For this project I have kept top 4 features for each row of data. I also have ignored the first highest feature as it comes from a constant 1 which act as a noise. I have plotted the original extracted data in **decreasing order** with the selected **top 4 data** on the bottom.

#### **Reason for choosing FFT**

It gives the peak of the CGM data at which meal was taken showing the rise of glucose level in the body. For now, this can be considered as a good feature for detecting the meal intake in the graph




All 31 graph for each and every person can be found under Person folder and subfolder FFT.

## 2.DISCRETE WAVELET TRANSFORM

Discrete wavelet transform uses different sets of wavelet scales and transition to find the frequency domain of the given series. It is more helpful in finding the change as compared to Fourier transform because it also captures the rate and location. For this also I have taken top 4 features as my feature matrix

### Reason for choosing DWT

Discrete Wavelet Transform is similar to FFT but the advantage of choosing DWT is that it capture the rate of change more accurately as compared to the FFT and also the time stamp if we want to know the exact location.



All 31 graph for each and every person can be found under Person folder and subfolder DWT.


### 3.VELOCITY

Velocity finds the rate of change between the  $t+1$  and  $t$  timestamp of the time series data. Its find the rate of change of the value between these points.

For this also I have taken top 4 features as my feature matrix

## Reason for choosing Velocity

It captures rate of change of y value which will help us to locate the maximum point and points around it and I selected the top 4 of those points as my features




All 31 graph for each and every person can be found under Person folder and subfolder Velocity.

## 4. MOVING AVERAGE

Moving average is used to create smooth version of the time series data set. It helps to remove any random noise that can be present over the series or any random fluctuations. I have used rolling function of pandas creating moving average for length 16. I have removed the NAN values in order to create plots and finding the maximum 4 values. For this also I have taken top 4 features as my feature matrix

## Reason for choosing Moving Average


Moving average smoothes the data and form a good features for creating a stationary points also keeping previous information.



All 31 graph for each and every person can be found under Person folder and subfolder RollingWindow.

## 5. EXPANDING WINDOW

Expanding windows is same as cumulative sum which keeps the record of all the past things and increases over time. Same happens in expanding window where number of observation increases over time.



All 31 graph for each and every person can be found under Person folder and subfolder ExpandingWindow.

### QUESTION 3

Drawbacks and Advantages of choosing all the 5 features above

1. Fast Fourier Transform- We have used FFT to capture the increase in the glucose level of a person when there is food intake. According to initial hypothesis it should have selected the points with high change in value but in some of the case it selected peak from graph with multiple maxima. It

doesn't capture the exact point where there is a spike but can also capture multiple points where there is not sudden increase. The other thing is we have to deal with real and imaginary points while dealing with FFT. Since most of the dataset has one single maxima it forms a decent feature. To avoid this I used DWT to look further

2. Discrete Wavelet Transform- In DWT both higher frequency window and lower frequency window helps to capture rate of change in glucose level more accurately as compared to the FFT.
3. Velocity- It tries to find the maximum point in the graph but sometimes lead to find the maximum point where these is least rate of change in the glucose level.
4. Moving Average- Its tries to smooth the graph and create stationary points with minimum change in the glucose level. It provides a constant value keeping the value close to the maxima if window size is selected properly.
5. Expanding Window- Expanding window is not at all helpful in this case as it keeps all the information from the past and doesn't help in finding the exact instantaneous change in the value.

Question 4

FEATURE MATRIX

I have created a FeatureExtracted.csv file which contains all the features that I have extracted using the above feature extraction technique. Since I have extracted 5 features having top 4 from each method we have matrix of size 32X20 for each person


Screenshot of the feature matrix

	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	
0	1349.4563506679900	1349.4563506679900	344.27408329703200	344.27408329703200	233.0	232.0	225.0	217.0		222.25	214.3125	205.125	167.6129032258000	164.6666666666700	161.44827586206000	157.82867142857100	566.2813126546320	362.03867196751200	362.03867196751200	352.13917703001000	
1	868.5430904989320	868.5430904989320	199.20048581924700	199.20048581924700	205.0	198.0	198.0	187.0		338.125	338.125	336.75	308.15384615384600	308.08	307.962962962963	307.75	494.974746830580	492.14631970593700	490.02499936227700	489.07139058109100	
2	1247.3743204817500	1247.3743204817500	255.89920870341400	255.89920870341400	61.0	60.0	59.0	58.0		248.125	244.625	239.1875	232.4375	192.9548387096600	191.63333333333300	190.0896951724100	198.0	383.95986218429500	381.83761618407360	370.52295334175100	367.8955262170050
3	1128.0697013218700	1128.0697013218700	290.5755218618800	290.5755218618800	94.0	91.0	83.0	75.0		202.375	195.8125	187.75	179.8125	150.9354838709600	146.36666666666700	145.51724137931000	142.78571428571400	322.4406922210960	320.31937187759000	304.763022691402	302.6417023478420
4	599.87119370007100	599.87119370007100	74.39778770742930	74.39778770742930	78.0	76.0	76.0	73.0		157.625	157.5	156.9375	156.75	143.4814814814820	143.3928674285700	143.34615384615400	143.241379310204500	234.7594519339340	232.83913191007400	229.12559710444100	224.869664173220
5	1147.9179502459900	1147.9179502459900	240.6741221218890	240.6741221218890	49.0	48.0	45.0	44.0		210.3125	206.9375	202.5	197.0625	158.6774354838900	156.86666666666700	154.86208989551700	152.71428571428600	316.78383797157300	311.1269837226910	304.05591591021500	303.34889012902900
6	697.7349832099500	697.7349832099500	176.909565402060	176.909565402060	64.0	63.0	60.0	57.0		172.125	170.125	166.3125	161.8125	140.2506451612900	138.51724137931000	137.3028574285700	263.043226019960	260.21529547665000	255.26554690834000	243.24472727817200	
7	1162.9193476377700	1162.9193476377700	258.0314476380010	258.0314476380010	47.0	46.0	45.0	45.0		196.875	190.1875	180.9375	151.74193548387100	140.2	146.41379310344800	143.42857142857100	325.2691193458120	322.4406922210960	321.7335854368790	318.6126569063020	
8	660.1121041543480	660.1121041543480	258.87960715519800	258.87960715519800	53.0	53.0	50.0	47.0		175.5	172.625	168.9375	164.75	144.4519162022260	143.03333333333300	141.55172413793100	140.0	264.457463769160	262.3396158202000	259.50818895463	253.85153444597100
9	480.5737160647950	480.5737160647950	122.3011905687700	122.3011905687700	86.0	85.0	85.0	84.0		171.25	171.0625	170.5	169.8125	157.0896621773900	157.0454545454500	156.83333333333300	156.4	272.2361107568810	266.5702595073280	262.3066158202000	251.022907321240
10	1088.2841625329400	1088.2841625329400	192.4376872295430	192.4376872295430	85.0	79.0	71.0	66.0		221.25	218.9375	215.1875	210.25	173.9354838709600	172.43333333333300	170.82758620689700	169.07142857142900	323.85405578343000	321.7335854368790	314.6625178380140	
11	1379.123632577880	1379.123632577880	327.5716422117920	327.5716422117920	49.0	47.0	47.0	47.0		205.9375	198.1875	189.5625	180.3125	146.38709677419400	143.7	140.6896517241400	137.32142857142900	340.1139617507290	340.1139617507290	329.5177600329310	323.85485076343900
12	773.131627455207	773.131627455207	152.11179119778000	152.11179119778000	30.0	29.0	21.0	20.0		189.25	186.9375	183.875	179.8125	154.8709677419360	153.8	152.51724137931000	151.03571428571400	282.15605699340200	280.72139213105900	276.4787514439400	275.064583781567
13	870.7581770303420	870.7581770303420	114.0897940683000	114.0897940683000	103.0	103.0	99.0	97.0		187.8125	186.9375	184.625	181.0625	150.3548387096770	150.13333333333300	149.72413793103400	148.89285714285700	289.9132829646980	285.67113956936500	283.5498162558060	272.23611075882100
14	218.4169598281000	218.4169598281000	165.9169471622890	165.9169471622890	98.0	97.0	93.0	92.0		109.6875	108.5625	107.375	106.375	101.19354838709700	100.53333333333300	99.79310344827560	99.07142857142860	171.11984104147600	171.11984104147600	167.5843074121200	167.5843074121200
15	926.8977217110280	926.8977217110280	246.99784537623000	246.99784537623000	46.0	43.0	43.0	42.0		187.375	182.375	176.125	169.4375	147.3548387096770	145.36666666666700	143.10344827586200	140.8074285714300	305.47012947258900	299.813272230960	295.57063455693700	292.7422074112310
16	795.096254206570	795.096254206570	152.796018084980	152.796018084980	153.0	152.0	151.0	150.0		210.4375	207.375	203.3125	198.375	175.06451912902200	173.7	172.1724137931000	170.53571428571400	309.0566337352100	308.29855669733500	308.29855669733500	307.127298237750
17	1299.7376489966500	1299.7376489966500	300.13840020850100	300.13840020850100	158.0	156.0	153.0	151.0		206.25	203.25	199.625	194.875	216.8	216.72727272727200	216.11111111111100	215.75	326.68332908185	318.905158315133	316.076711903870	307.6918548795370
18	811.8540602987890	811.8540602987890	252.33446283951900	252.33446283951900	57.0	54.0	51.0	50.0		161.4375	157.4375	152.1875	146.0	123.6451612903200	121.76666666666700	119.8896511724140	117.5	256.679161570710	254.55844122715700	244.6584629954500	236.98172670882900
19	817.6580657593230	817.6580657593230	82.5569619239270	82.5569619239270	23.0	20.0	18.0	17.0		183.25	182.5625	182.25	180.625	150.6551724137930	150.43333333333300	150.25959259592500	287.7924994292950	285.67113956936500	275.06453798156700	268.5792565073280	
20	644.6329574013310	644.6329574013310	99.98721696408550	99.98721696408550	115.0	109.0	107.0	100.0		180.75	180.6875	179.3125	178.75	155.82857142857100	155.92592592592600	155.51724137931000	155.46153846153800	285.67113956936500	270.82189718944800	265.16504294493500	263.70892385258200
21	103.82036210302000	103.82036210302000	55.46975743328780	55.46975743328780	113.0	111.0	110.0	105.0		93.625	93.625	93.0	90.75	96.83333333333300	94.71428571428570	144.249783820560	140.71424945612300	140.71424945612300	140.0071426749980		
22	582.7456530539670	582.7456530539670	116.13065290043000	116.13065290043000	79.0	74.0	64.0	64.0		179.5625	179.0	177.25	174.75	157.43333333333300	157.3793103448280	157.19354838709700	157.03571428571400	284.9640328181790	283.5498162558060	271.5290207782300	261.629509399230
23	528.5184072237700	528.5184072237700	120.6888380138810	120.6888380138810	105.0	101.0	91.0	86.0		134.1875	133.5625	132.75	131.0	113.10714285714300	113.03703703703700	112.75862068965500	112.42307982307700	234.35385916291200	201.5254263819600	197.8998987322330	194.4543648263010
24	796.1537596929390	796.1537596929390	163.28000022656500	163.28000022656500	101.0	100.0	99.0	96.0		193.5	191.9375	188.75	184.5	158.4516129032260	157.86666666666700	156.89655172413800	155.57142857142900	299.813275230960	287.7924994292950	287.08535139173800	280.01428534987390
25	385.76656729822700	385.76656729822700	84.34530179773210	84.34530179773210	60.0	58.0	45.0	32.0		118.5625	118.25	117.9375	117.1875	100.57142857142900	100.51724137931000	100.38461538461500	188.7975105768800	177.48380207782300	171.82994782832100	171.82994782832100	
26	261.4127061367000	261.4127061367000	176.8712384876570	176.8712384876570	61.0	59.0	59.0	58.0		100.125	99.875	99.875	99.875	99.4375	136.5	126.0	121.28571428571400	209.30389723121800	176.7766592663700	161.92745289171900	161.22034610533300
27	255.83978165520700	255.83978165520700	205.89918165520700	205.89918165520700	92.0	80.0	74.0	74.0		152.4375	149.375	146.6875	144.5	181.25	178.8	175.33333333333300	171.71428571428600	261.6295099029320	251.0229073212400	231.22991742800100	210.010740124090
28	588.4407678155290	588.4407678155290	181.73265031468900	181.73265031468900	87.0	87.0	84.0	80.0		168.6875	164.75	163.9375	157.3125	141.83870967741900	140.23333333333300	138.79310344827600	137.46428571428600	268.7057685088800	263.14422706479400	242.53702594898600	241.83051916579900
29	528.2257404777900	528.2257404777900	112.91477494003000	112.91477494003000	98.0	98.0	98.0	97.0		157.625	151.0625	144.625	138.75	192.75	191.4	190.66666666666700	189.42857142857100	285.01428534987300	265.1650429449500	263.70892385258200	242.53762949968900
30	290.523469599970	290.523469599970	121.9871927807560	121.9871927807560	43.0	42.0	41.0	38.0		110.3125	110.25	110.0625	109.0	108.83333333333300	108.76470588235300	108.42857142857100	185.9998345206200	175.36248179434900	170.17273426595800	159.8012584516000	
31	200.06479310481100	200.06479310481100	116.022291789000	116.022291789000	58.0	53.0	52.0	51.0		127.375	127.375	127.375	127.375	121.21428571428600	121.19518518518500	121.0	120.86208989551700	188.09400375962200	185.261967087500	185.261967087500	




Question 5


PRINCIPAL COMPONENT ANALYSIS

For principal component analysis I am using the extracted feature matrix as input for PCA function from sklearn. It outputs an array of 31X5 matrix consisting of 5 principal components. Along with that I have created an eigen value matrix of 5X20 to see the contribution of each extracted feature on the 5 components. Plots of eigen value matrix. Plotted all the five components in time series below.









## Question 6

First principal component shows FFT, Moving Average and DFT as the most important feature. The variance for PC1 is around 63% among all the principal components

The second principal component shows Velocity and Expanding window as the most important feature. The variance for PC1 is around 19% among all the principal components

The third principal component shows Velocity and FFT as the most important feature. The variance for PC3 is around 11% among all the principal components

The fourth principal component shows Expanding window as the most important feature. The variance for PC4 is around 3% among all the principal components

Similarly it can be seen for all the Principal components in the figure plotted above. I have also made a heatmap using seaborn library for analysis.

